# 03-skimage-images

January 13, 2020

# 1 Image representation in skimage

```
1.0.1 Reading images
```

```
In []: from matplotlib import pyplot as plt
    import skimage.io
In []: image = skimage.io.imread(fname="../data/chair.tif")

1.0.2 Displaying images
In []: import skimage.viewer
In []: # display image
    viewer = skimage.viewer.ImageViewer(image)
    viewer.show()

1.0.3 Saving images
In []: # save a new version in .png format
    skimage.io.imsave(fname="chair.png", arr=image)

1.0.4 Images are represented as NumPy arrays
In []: import numpy
    print("shape:", image.shape, "dtype:", image.dtype)
In []: print("min", numpy.min(image), "max", numpy.max(image), "mean", numpy.mean(image))
```

# 1.0.5 Exercise: Resize an image you took on your phone

- copy image from phone to the data folder
- load the image
- resize the image using skimage.transform.resize()
- save the resized image

```
In []: import skimage.transform

# read in image
image = skimage.io.imread(fname="../data/chair.tif")

# resize the image
new_shape = (image.shape[0] // 16, image.shape[1] // 16, image.shape[2])
small = skimage.transform.resize(image=image, output_shape=new_shape)

# write out image
skimage.io.imsave(fname="resized.tif", arr=small)
```

## 1.0.6 Manipulating pixels

#### ignore low intensity pixels

```
In []: import skimage.io
    import skimage.viewer

# read input image, based on filename parameter
    image = skimage.io.imread("../data/roots-bw.tif", as_gray=True)

# display original image
    viewer = skimage.viewer.ImageViewer(image)
    viewer.show()

In []: # keep only high-intensity pixels
    image[image < 128] = 0

# display modified image
    viewer = skimage.viewer.ImageViewer(image)
    viewer.show()</pre>
```

#### 1.0.7 Exercise: Keeping only low intensity pixels

- load the ../data/sudoku.png image
- show the original image
- set pixels with values greater than 200 (white) to gray
- show the modified image

```
In []: import skimage.io
    import skimage.viewer

# read input image, based on filename parameter
    image = skimage.io.imread("../data/sudoku.png", as_gray=True)

# display original image
    viewer = skimage.viewer.ImageViewer(image)
    viewer.show()
```

```
image[image > 128] = 64
        # display modified image
        viewer = skimage.viewer.ImageViewer(image)
        viewer.show()
1.0.8 Converting color images to grayscale
In []: # read input image, based on filename parameter
        image = skimage.io.imread("../data/chair.tif")
        # display original image
        viewer = skimage.viewer.ImageViewer(image)
        viewer.show()
        # convert to grayscale and display
        gray_image = skimage.color.rgb2gray(image)
        viewer = skimage.viewer.ImageViewer(gray_image)
        viewer.show()
In [ ]: # read input image, based on filename parameter
        image = skimage.io.imread("../data/chair.tif", as_gray=True)
        # display grayscale image
        viewer = skimage.viewer.ImageViewer(image)
        viewer.show()
1.0.9 Access via slicing
In [ ]: image = skimage.io.imread("../data/roots.tif")
        clip = image[1600:1900, 1700:2200, :]
        # display grayscale image
        viewer = skimage.viewer.ImageViewer(clip)
        viewer.show()
In [ ]: color = image[1800, 1900]
        print(color)
        image[1600:1900, 1700:2200] = color
        viewer = skimage.viewer.ImageViewer(image)
        viewer.show()
```

# keep only high-intensity pixels

## 1.0.10 Exercise: Practicing with slices

- Load the code in the cell below and modify the program to
- create,

- display, and
- save

a sub-image containing only the plant and its roots. Use ImageJ to determine the bounds of the area you will extract using slicing.

#### 1.0.11 Exercise: Metadata

Explore how skimage handles metadata.

- Open the maize-roots.tif image in the data folder in Fiji. Look at the metadata by going to *Image -> Info*
- read the image here and write out a copy to maize-roots-copy.tif, check out the metadata in Fiji agian.

What happened to the metadata?

#### 1.0.12 Exercise: Slicing and the colorimetric challenge

- Consider the image titration.tif in the data directory
- We want to sample the color channel values from an image of a solution. To make our graph
  more reliable, we will want to calculate a mean channel value over several pixels, rather than
  simply focusing on one pixel from the image.

#### 1.0.13 Keypoints

- skimage images are stored as three-dimensional NumPy arrays.
- In skimage images, the red channel is specified first, then the green, then the blue, i.e. RGB.
- Images are read from disk with the skimage.io.imread() function.
- We create a window that automatically scales the displayed image with skimage.viewer.ImageViewer() and calling view() on the viewer object.

- Color images can be transformed to grayscale using skimage.color.rgb2gray() or be read as grayscale directly by passing the argument as\_gray=True to skimage.io.imread().
- We can resize images with the skimage.transform.resize() function.
- NumPy array commands, like img[img < 128] = 0, and be used to manipulate the pixels of an image.
- Array slicing can be used to extract sub-images or modify areas of images, e.g., clip = img[60:150, 135:480, :].
- Metadata is not retained when images are loaded as skimage images.